


ENGINEERING  
TOMORROW



Service Manual

# D1 High Power Open Circuit Pumps

Size 130/145/193/260



**Revision history***Table of revisions*

| <b>Date</b>  | <b>Changed</b>                         | <b>Rev</b> |
|--------------|----------------------------------------|------------|
| October 2017 | Added Size 130                         | 0103       |
| June 2016    | Added Size 260                         | 0102       |
| April 2016   | Converted to Danfoss layout - DITA CMS | 0101       |
| July 2015    | Added 145 cc information               | AB         |
| January 2014 | First edition                          | AA         |

**Contents**

**Introduction**

Overview.....5  
 General Instructions.....5  
     Remove the Unit.....5  
     Keep it Clean.....5  
     Replace all O-rings and Gaskets.....5  
     Secure the Unit.....5  
 Safety Precautions.....6  
     Unintended Machine Movement.....6  
     Flammable Cleaning Solvents.....6  
     Fluid Under Pressure.....6  
     Personal Safety.....6  
     Hazardous Material.....6  
 Symbols used in Danfoss literature.....7  
 Design.....8

**Operation**

TPSN (Power Control + Pressure Compensated Control + Load Sensing Control)..... 9  
 TPE2/TPE5 (Power Control + Pressure Compensated Control + Electric Displacement Control)..... 12

**Operating Parameters**

Pressure..... 15  
 Speed..... 15  
 Fluid..... 15  
     Viscosity..... 16  
     Temperature..... 16  
     Fluid Velocity..... 16

**Technical Specifications**

Pump Specifications..... 17  
 Fluid Specifications..... 17

**Fluid and Filter Maintenance**

Recommendations of fluid and filter maintenance..... 19

**Pressure Measurements**

Port Locations and Gauge Installation (130/145)..... 20  
 Port Locations and Gauge Installation (193/260)..... 21

**Initial Start-up Procedures**

General..... 22  
 Start-up Procedure..... 22

**Troubleshooting**

Excessive Noise and /or Vibration..... 23  
 Low Pump Output Flow..... 23  
 No or Low System Pressure..... 24  
 Actuator Response is Sluggish..... 24  
 Pressure or Flow Instability..... 24  
 System Operating Hot..... 25  
 High Inlet Vacuum..... 25

**Adjustments**

TPE2 Control (193/260)..... 26  
 TPSN Control (193/260)..... 29  
 TPSN Control (130/145)..... 31  
 Displacement Limiters Adjustment..... 32  
     Adjust Displacement Limiters..... 32

**Minor Repair**

Shaft Seal Replacement..... 33  
     Removal..... 33  
     Installation..... 33

**Contents**

|                                                   |    |
|---------------------------------------------------|----|
| Auxiliary Flange and Charge Pump Replacement..... | 34 |
| Removal.....                                      | 34 |
| Installation.....                                 | 34 |
| 130/145.....                                      | 34 |
| 193/260.....                                      | 35 |
| Control (193/260).....                            | 36 |
| Removal.....                                      | 36 |
| Installation.....                                 | 36 |
| Control (130/145).....                            | 37 |
| Shuttle Valve or Plug.....                        | 38 |
| Removal.....                                      | 38 |
| Installation.....                                 | 38 |
| Edge Filter (260).....                            | 38 |
| Removal.....                                      | 38 |
| Installation.....                                 | 38 |
| Displacement Limiters.....                        | 39 |
| Removal.....                                      | 39 |
| Installation.....                                 | 39 |
| Plug and Fitting Sizes and Torques.....           | 40 |
| 193 TPE2 Control.....                             | 40 |
| 260 TPE2 Control.....                             | 41 |
| 130/145 TPSN Control.....                         | 41 |
| Torque Chart.....                                 | 42 |
| Fastener Size and Torque Chart.....               | 42 |
| Plug Size and Torque Chart.....                   | 43 |

## Introduction

### Overview

This manual includes information for the installation, maintenance, and minor repair of the D1 pumps. It includes a description of the unit and its individual components, troubleshooting information, and minor repair procedures.

Performing minor repairs may require removal from the vehicle/machine. Thoroughly clean the unit before beginning maintenance or repair activities. Since dirt and contamination are the greatest enemies of any type of hydraulic equipment, follow cleanliness requirements strictly. This is especially important when changing the system filter and when removing hoses or plumbing.

A worldwide network of Danfoss Authorized Service Centers (ASCs) is available for major repairs. Major repairs require the removal of the unit's endcap, which voids the warranty unless done by an ASC. Danfoss ASCs are trained by the factory and certified on a regular basis. You can locate your nearest ASC using the distributor locator at [www.powersolutions.danfoss.com](http://www.powersolutions.danfoss.com)

### General Instructions

Follow these general procedures when repairing D1 variable displacement open circuit pump.

#### Remove the Unit



Prior to performing repairs, remove the unit from the vehicle/machine. Chock the wheels on the vehicle or lock the mechanism to inhibit movement. Be aware that hydraulic fluid may be under high pressure and/or hot. Inspect the outside of the pump and fittings for damage. Cap hoses after removal to prevent contamination.

#### Keep it Clean



Cleanliness is a primary means of assuring satisfactory pump life on either new or repaired units. Clean the outside of the pump thoroughly before disassembly. Take care to avoid contamination of the system ports. Cleaning parts by using a clean solvent wash and air drying is usually adequate.

As with any precision equipment, you must keep all parts free of foreign material and chemicals. Protect all exposed sealing surfaces and open cavities from damage and foreign material. If left unattended, cover the pump with a protective layer of plastic.

#### Replace all O-rings and Gaskets



We recommend you replace all O-rings and seals during service. Lightly lubricate O-rings with clean petroleum jelly prior to assembly.

#### Secure the Unit



For repair, place the unit in a stable position with the shaft pointing downward. It will be necessary to secure the pump while removing and torquing fasteners and components.

## Introduction

### Safety Precautions

Always consider safety precautions before beginning a service procedure. Protect yourself and others from injury. Take the following general precautions whenever servicing a hydraulic system.

#### Unintended Machine Movement

 **Warning**

---

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable/disconnect the mechanism while servicing.

---

#### Flammable Cleaning Solvents

 **Warning**

---

Some cleaning solvents are flammable. To avoid possible fire, do not use cleaning solvents in an area where a source of ignition may be present.

---

#### Fluid Under Pressure

 **Warning**

---

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. This fluid may also be hot enough to cause burns. Use caution when dealing with hydraulic fluid under pressure. Relieve pressure in the system before removing hoses, fittings, gauges, or components. Never use your hand or any other body part to check for leaks in a pressurized line. Seek medical attention immediately if you are cut by hydraulic fluid.

---

#### Personal Safety

 **Warning**

---

Protect yourself from injury. Use proper safety equipment, including safety glasses, at all times.

---

#### Hazardous Material

 **Warning**





























---

Hydraulic fluid contains hazardous material. Avoid prolonged contact with hydraulic fluid. Always dispose of used hydraulic fluid according to state, and federal environmental regulations.

---

## Introduction

### Symbols used in Danfoss literature

|                                                                                     |                                                     |                                                                                      |                                                      |
|-------------------------------------------------------------------------------------|-----------------------------------------------------|--------------------------------------------------------------------------------------|------------------------------------------------------|
|    | WARNING may result in injury                        |    | Tip, helpful suggestion                              |
|    | CAUTION may result in damage to product or property |    | Lubricate with hydraulic fluid                       |
|    | Reusable part                                       |    | Apply grease / petroleum jelly                       |
|    | Non-reusable part, use a new part                   |    | Apply locking compound                               |
|    | Non-removable item                                  |    | Inspect for wear or damage                           |
|    | Option - either part may exist                      |    | Clean area or part                                   |
|    | Superseded - parts are not interchangeable          |    | Be careful not to scratch or damage                  |
|    | Measurement required                                |    | Note correct orientation                             |
|    | Flatness specification                              |    | Mark orientation for reinstallation                  |
|    | Parallelism specification                           |    | Torque specification                                 |
|    | External hex head                                   |    | Press in - press fit                                 |
|   | Internal hex head                                   |   | Pull out with tool – press fit                       |
|  | Torx head                                           |  | Cover splines with installation sleeve               |
|  | O-ring boss port                                    |  | Pressure measurement/gauge location or specification |

The symbols above appear in the illustrations and text of this manual. They are intended to communicate helpful information at the point where it is most useful to the reader. In most instances, the appearance of the symbol itself denotes its meaning. The legend above defines each symbol and explains its purpose.

**Introduction**


**Design**

Danfoss D1 high power open circuit piston pumps convert input torque into hydraulic power. Rotational force is transmitted through the input shaft to the cylinder block. The input shaft is supported by roller bearings at the front and rear of the pump and is splined into the cylinder block. A lip-seal at the front end of the pump prevents leakage where the shaft exits the pump housing. The spinning cylinder block contains nine reciprocating pistons. Each piston has a brass slipper connected at one end by a ball joint. The slippers are held to the swashplate by the retainer. The block spring holds the cylinder block to the valve plate. The reciprocating movement of the pistons occurs as the slippers slide against the inclined swashplate during rotation. Via the valve plate, one half of the cylinder block is connected to pump inlet and the other half to pump outlet. As each piston cycles in and out of its bore, fluid is drawn from the inlet and displaced to the outlet thereby imparting power into the system circuit. A small amount of fluid is allowed to “leak” from the cylinder block / valve plate and slipper / swashplate interfaces for lubrication and cooling. Case drain ports are provided to return this fluid to the reservoir.

The volume of fluid displaced into the system circuit is controlled by the angle of the swashplate. The swashplate is forced into an inclined position (into stroke) by the bias piston and spring. The servo piston opposes the action of the bias piston and spring forcing the swashplate out of stroke.

The pump control, by varying the pressure at the servo piston, controls the displacement of fluid in the system circuit.

*Series D1 Pump Cross-Section View\**




- |                                 |                    |                                 |
|---------------------------------|--------------------|---------------------------------|
| 1. Shaft Seal                   | 2. Roller Bearing  | 3. Housing                      |
| 4. Minimum Displacement Limiter | 5. Bias Piston     | 6. Control                      |
| 7. Valve Plate                  | 8. Endcap          | 9. Charge Pump                  |
| 10. Servo Piston                | 11. Cylinder Block | 12. Maximum Displacement Limite |
| 13. Piston                      | 14. Swashplate     | 15. Swashplate Bearing          |
| 16. Input Shaft                 |                    |                                 |

\*Some internal parts may be different depend on different pump size.





Operation

TPSN (Power Control + Pressure Compensated Control + Load Sensing Control)



P400252


D1P 130/145+TPSN




P400079

D1P 193/260+TPSN


\*Control oil filter is optional




T Characteristic



P Characteristic



S Characteristic



P400081

## Operation

### Power Control (T) Principle

The power control regulates the displacement of the pump depending on the working pressure so that a given drive power is not exceeded at constant drive speed, this function can prevent engine stall or protect electric generator.

$$P_B \cdot V_g = C$$

$P_B$  = working pressure  
 $V_g$  = displacement  
 $C$  = constant

The precise control with a hyperbolic control characteristic, provides an optimum utilization of available power.

### Power Control (T) Operation

The working pressure acts on a rack-pivot via a roller jack which produce a rotate torque, an externally adjustable spring force counteracts this which determines the power setting.

If the moment generated by working pressure exceeds the moment generated by spring force, the control valve is actuated by the rack-pivot, pump reduces displacement. The lever length at the rack-pivot is shortened and the working pressure can increase at the same rate as the displacement decreases without the drive powers being exceeded.

$$(P_B \cdot V_g = C).$$

The hydraulic output power (characteristic T) is influenced by the efficiency of the pump.

### Pressure Compensated Control (P) Principle

The P control design maintains a constant pressure in the hydraulic circuit as flow varies. The P control modulates pump flow accordingly to maintain system pressure at the P setting as the P adjusting screw and spring defines.

### Pressure Compensated Control (P) Operation

When system pressure, acting on the non-spring end of the P spool ,overcomes the force of the P spring, the spool shifts porting system pressure to the servo piston and the swashplate angle decreases. When system pressure drops below the P setting, the P spring shifts the spool in the opposite direction connecting the servo piston to pump case and the swashplate angle increases. The swashplate is maintained at whatever angle is required to keep system pressure at the P setting.

### Load Sensing Control (S) Principle

The S control design matches pump flow with system demand. The S control senses the flow demand of the system as a pressure drop across the external control valve (1).

As the (1) opens and closes, the pressure delta across the valve changes. When opening, the delta decreases. When closing, the delta increases. The S control then increases or decreases pump flow to the system until the pressure delta becomes equal to the S setting as defined by the S adjusting screw and spring .

### Load Sensing Control (S) Operation

Through internal porting, system pressure [upstream of (1)] is applied to the non-spring end of the S spool, and through hydraulic line connected at port X, load pressure [downstream of (1)] is applied to the spring end. This arrangement allows the S spool to act on the delta between system pressure and load pressure. The S spring sets the threshold of operation (S setting).

Because the swashplate is biased to maximum angle, the pump attempts to deliver full flow to the hydraulic system. When the flow being delivered exceeds demand, the pressure delta across the (1) is

## Operation

great enough to overcome spring force and shift the S spool porting system pressure to the servo piston. The pump de-strokes reducing flow until the delta across the (1) becomes equal to the S setting.

When flow being delivered is less than demand, the delta across the (1) drops below the S setting and the S spring shifts the spool connecting the servo piston to pump case. The pump strokes increasing flow until the delta across the (1) becomes equal to the S setting.


When the external control valve (1) is placed in neutral, it connects the LS signal line to drain. With no LS pressure acting on the non-spring end of the LS spool, the pump adjusts stroke to whatever position necessary to maintain system pressure at the LS setting. The pump is now in low pressure standby mode. (1) is not in the scope of supply.

### **TPSN Priority**

The Pressure Compensated Control (P) has priority over the Power Control (T), and the Power Control (T) has priority over the Load Sensing (S).

## Operation

### TPE2/TPE5 (Power Control + Pressure Compensated Control + Electric Displacement Control)




**Warning**

(1) Adjustment is not permissible


D1P 193/260+TPE2

\*Control oil filter is optional




## Characteristics


### T Characteristic



### P Characteristic



### E2/E5 characteristics



## Displacement Principle and Operation

### Power Control (T) Principle and Operation

Please refer [TPSN \(Power Control + Pressure Compensated Control + Load Sensing Control\)](#) on page 9

### Pressure Compensated Control (P) Principle and Operation

Please refer [TPSN \(Power Control + Pressure Compensated Control + Load Sensing Control\)](#) on page 9

### Electric Displacement Control (E2/E5) Principle

The electric displacement control uses an electric proportional solenoid valve to vary the pump's displacement from minimum displacement to maximum displacement or from maximum displacement to minimum displacement. The swashplate angle (pump displacement) is proportional to the electrical input signal (control current).

### Electric Displacement Control (E2/E5) Operation

E2/E5 is current driven control requiring a Pulse Width Modulated (PWM) signal. Pulse width modulation allows more precise control of current to the solenoid. The PWM signal causes the solenoid pin to push against the E2/E5 spool, which depressurizes the end of servo piston, the swashplate angle increases under the force of bias piston.

## Operation

A swashplate feedback link provides swashplate position force to the solenoid through E2/E5 spool linear spring. The control reaches equilibrium when the position of the swashplate spring feedback force exactly balances the input command solenoid force from the operator. As working pressure changes with load, the control and servo/swashplate system work constantly to maintain the commanded position of the swashplate.

### **Electric Displacement Control (E2/E5) Operating Instruction**

To make sure the electric displacement control works properly, a minimum control pressure of 30 bar is required. The required control pressure is taken either from the working pressure, or from the externally applied control pressure at the E port.

If you can't make sure that the working pressure is above 30 bar all the time, then 30bar pressure at the E port is mandatory.

If E port is not connected , remove the shuttle valve.

### **MOR**

The electric displacement control with Manual Over Ride (MOR) function for temporary actuation of the control to aid in diagnostics.

### **⚠ Warning**

Do not actuate MOR unless the machine is in a "SAFE" mode.

## Solenoid Specifications

### *Technical data - Solenoid*

|                                                                          |            |
|--------------------------------------------------------------------------|------------|
| <b>Voltage</b>                                                           | 24V (±20%) |
| <b>Start current at Vg min</b>                                           | 200 mA     |
| <b>End Current at Vg max</b>                                             | 600 mA     |
| <b>Maximum current</b>                                                   | 770 mA     |
| <b>Coil resistance @ 20 °C [70 °F]</b>                                   | 22.7 Ω     |
| <b>PWM Range</b>                                                         | 70~200 Hz  |
| <b>PWM Frequency (preferred)*</b>                                        | 100 Hz     |
| <b>IP Rating (IEC 60 529) + DIN 40 050, part 9</b>                       | IP 67      |
| <b>IP Rating (IEC 60 529) + DIN 40 050, part 9 with mating connector</b> | IP 69K     |

\* PWM signal required for optimum control performance

### *Mating connector for Solenoid*

| Description                                                                                                 | Ordering Number | Quantity |
|-------------------------------------------------------------------------------------------------------------|-----------------|----------|
| Danfoss mating connector kit                                                                                | K29657          | 1        |
| The mating connector is not included in the delivery contents, this can be delivered by Danfoss on request. |                 |          |

*Below compatible PLUS+1® controllers are available:*

|       |          |
|-------|----------|
| MC012 | L1301095 |
| MC024 | L1315302 |
| MC038 | 11051653 |

**Operation**

*Below compatible PLUS+1® controllers are available: (continued)*

|       |          |
|-------|----------|
| MC050 | L1301752 |
| MC088 | 11006645 |

*For further information:*

You can see <http://www.danfoss.com/Products/MobileElectronics/index.htm>

**Standard EDC Valve**


The position of the connector can be changed by turning the solenoid body. Proceed as follows:

1. Loosen protect cap (1).
2. Loosen lock nut (2).
3. Turn the solenoid body (3) to the desired position.
4. Tighten the lock nut (2).
5. Tighten the protect cap (1).

Tightening torque of lock nut:  $5 \pm 1$  N·m.

The Pressure Compensated Control (P) has priority over the Power Control (T), and the Power Control (T) has priority over Electric Displacement Control (EDC) .

*Standard EDC Valve*



**A** At first actuation breakaway force max.45N; Repeat of actuation max.25N.

## Operating Parameters

### Pressure

**Maximum working pressure** is the highest recommended outlet (application) pressure. Maximum working pressure is not intended to be a continuous pressure. For all applications, the load should move below this pressure. This corresponds to the maximum allowable pressure compensated control setting.

**Maximum (peak) pressure** is the highest intermittent ( $t < 1s$ ) outlet pressure allowed. Maximum machine load should never exceed this pressure, and pressure overshoots should not exceed this pressure.

**Inlet pressure** is the absolute pressure in the pump suction port, it is related to pump speed. Make sure it is in the allowable range, see [Pump Specifications](#) on page 17.

**Case pressure** : The case pressure at the ports L1 and L2 may be a maximum of 1.2 bar higher than the inlet pressure at the port S but not higher than 2bar. Size drain plumbing accordingly and connect it to tank directly .The housing must always be filled with hydraulic fluid.


### Speed

**Rated speed** is the fastest recommended operating speed at full displacement and at least 0.8 bar abs with charge pump (1 bar abs without charge pump) inlet pressure. Operating at or below this speed should yield satisfactory product life.

**Maximum speed** is the highest recommended operating speed at full power conditions. Operating at or beyond maximum speed requires positive inlet pressure and/or a reduction of pump outlet flow. Refer to [Inlet pressure vs. speed](#) on page 15 chart below.

**Minimum speed** is the lowest operating speed allowed. Operating below this speed will not yield satisfactory performance.

*Inlet pressure vs. speed*



### ! Caution

#### Duty cycle and pump life

Knowing the operating conditions of your application is the best way to ensure proper pump selection. With accurate duty cycle information, your Danfoss Power Solutions representatives can assist in calculating expected pump life.

### Fluid

Ratings and performance data for D1 pump are based on operating with premium hydraulic fluids containing oxidation, rust, and foam inhibitors. These include premium turbine oils, API CD engine oils per SAE J183, M2C33F or G automatic transmission fluids (ATF), Dexron II (ATF) meeting Allison C-3 or Caterpillar T0-2 requirements, and certain specialty agricultural tractor fluids. For more information on hydraulic fluid selection, see Danfoss Power Solutions publications **520L0463** *Hydraulic Fluids and Lubricants*, Technical Information, and **520L0465** *Experience with Biodegradable Hydraulic Fluids*, Technical Information.

## Operating Parameters

### Viscosity

**Minimum Viscosity:** This should only occur during brief occasions of maximum ambient temperature and severe duty cycle operation.

**Maximum Viscosity:** This should only occur at cold start. Pump performance will be reduced. Limit speeds until the system warms up.

Maintain fluid viscosity within the recommended range for maximum efficiency and pump life.

### Temperature

**Minimum temperature** relates to the physical properties of the component materials. Cold oil will not affect the durability of the pump components. However, it may affect the ability of the pump to provide flow and transmit power.

**Maximum temperature** is based on material properties. Don't exceed it. Measure maximum temperature at the hottest point in the system. This is usually the case drain.

### Fluid Velocity

Choose piping sizes and configurations sufficient to maintain optimum fluid velocity, and minimize pressure drops. This reduces noise, pressure drops, and overheating. It maximizes system life and performance.

#### *Recommended fluid velocities*

|                     |              |
|---------------------|--------------|
| <b>System lines</b> | 6 to 9 m/sec |
| <b>Suction line</b> | 1 to 2 m/sec |
| <b>Case drain</b>   | 3 to 5 m/sec |

Typical guidelines; obey all pressure ratings.

### Velocity equations

#### **SI units**

Q = flow (l/min)

A = area (mm<sup>2</sup>)

Velocity = (16.67•Q)/A (m/sec)



## Technical Specifications

### Pump Specifications

(theoretical values, without efficiency and tolerances; values rounded)

| Features                                               |                                      | Unit                    | Size                |                    |                    |                    |
|--------------------------------------------------------|--------------------------------------|-------------------------|---------------------|--------------------|--------------------|--------------------|
|                                                        |                                      |                         | Without Charge Pump | With Charge Pump   | With Charge Pump   | With Charge Pump   |
|                                                        |                                      |                         | 130/145             | 130/145            | 193                | 260                |
| Displacement                                           | Maximum                              | cm <sup>3</sup>         | 130/145             | 130/145            | 193                | 260                |
|                                                        | Minimum                              |                         | 0                   | 0                  | 0                  | 0                  |
| Working input speed                                    | Maximum at Vg max                    | min <sup>-1</sup> (rpm) | 2200 <sup>1)</sup>  | 2500 <sup>2)</sup> | 2500 <sup>2)</sup> | 2300 <sup>2)</sup> |
|                                                        | Maximum at Vg ≤ Vg max <sup>3)</sup> |                         | 2500                | 2500               | 2500               | 2300               |
| Flow at n max and Vg max                               |                                      | l/min                   | 273/319             | 325/363            | 483                | 598                |
| Working pressure                                       | Maximum                              | bar                     | 350                 | 350                | 350                | 350                |
|                                                        | Peak                                 |                         | 400                 | 400                | 400                | 400                |
| Inlet pressure (Absolute)                              | Minimum                              | bar                     | 0.8                 | 0.6                | 0.6                | 0.6                |
|                                                        | Maximum                              |                         | 30 <sup>4)</sup>    | 2                  | 2                  | 2                  |
| Case pressure (Absolute)                               | Maximum above inlet                  | bar                     | 1.2                 | 1.2                | 1.2                | 1.2                |
|                                                        | Maximum                              |                         | 2                   | 2                  | 2                  | 2                  |
| Filling capacity                                       |                                      | L                       | 2.9                 | 2.9                | 3.8                | 4.6                |
| Torque at Vg max and Δp = 350 bar                      |                                      | N•m                     | 724/808             | 724/808            | 1075               | 1448               |
| Power at Q max and Δp = 350 bar                        |                                      | kw                      | 159/186             | 190/211            | 281                | 349                |
| Mass moment of inertia of internal rotating components |                                      | kg•m <sup>2</sup>       | 0.0299              | 0.0306             | 0.0576             | 0.2080             |
| Mass (approx.)                                         |                                      | kg                      | 68                  | 74                 | 106                | 141                |
| External shaft loads                                   | Me                                   | N•m                     | 476                 | 476                | 822                | 1081               |
|                                                        | Thrust in (Tin), out (Tout)          | N                       | -2340/5073          | -2340/5073         | -3990/5570         | -3570/7180         |
| Mounting flange load moments                           | Vibratory (continuous)               | N•m                     | 4553                | 4553               | 6286               | 8477               |
|                                                        | Shock (maximum)                      |                         | 8692                | 8692               | 13782              | 16338              |

<sup>1)</sup> The values apply at absolute pressure (Pabs) of at least 1 bar at the suction port S and mineral hydraulic fluid.

<sup>2)</sup> The values apply at absolute pressure (Pabs) of at least 0.8 bar at the suction port S and mineral hydraulic fluid.

<sup>3)</sup> The values apply at Vg ≤ Vg max or in case of an increase in the inlet pressure (Pabs) at the suction port S.

<sup>4)</sup> If the application requires the higher inlet pressure than 5 bar (up to 30 bar), please contact Danfoss Power Solutions.

### Caution

Exceeding the permissible values could cause a loss of function, reduced life or the destruction of the pump.

### Fluid Specifications

| Features          | Units                 |                                    |
|-------------------|-----------------------|------------------------------------|
| Viscosity         | mm <sup>2</sup> /sec. | intermittent <sup>1)</sup>         |
|                   |                       | Minimum                            |
|                   |                       | Recommended range                  |
|                   |                       | Maximum (cold start) <sup>2)</sup> |
| Temperature range | °C                    | Minimum (cold start) <sup>2)</sup> |
|                   |                       | Maximum intermittent <sup>1)</sup> |

**Technical Specifications**

| Features                 |             | Units |          |
|--------------------------|-------------|-------|----------|
| Filtration (minimum)     | -40 - 90 °C |       | 20/18/15 |
| Cleanliness per ISO 4406 | 90 - 115 °C |       | 19/17/14 |

<sup>1)</sup> Intermittent = Short term  $t < 3\text{min}$  per incident.

<sup>2)</sup> Cold start = Short term  $t < 3\text{min}$ ,  $p \leq 30\text{ bar}$ ,  $n \leq 1000\text{ min}^{-1}(\text{rpm})$ , please contact Danfoss Power Solutions especially when the temperature is below  $-25\text{ °C}$ .

<sup>3)</sup> Must not be exceeded locally either (e.g. in the bearing area). The temperature in the bearing area is (depending on pressure and speed) up to  $5\text{ °C}$  higher than the average case drain temperature.

## Fluid and Filter Maintenance

### Recommendations of fluid and filter maintenance

To ensure optimum life of D1 pumps, perform regular maintenance of the fluid and filter. Contaminated fluid is the main cause of unit failure. Take care to maintain fluid cleanliness when servicing.

Check the reservoir daily for proper fluid level, the presence of water, and rancid fluid odor. Water in the fluid may be noted by a cloudy or milky appearance or free water in the bottom of the reservoir. Rancid odor indicates the fluid has been exposed to excessive heat. Change the fluid immediately if these conditions occur. Correct the problem immediately.

Change the fluid and filter per the vehicle / machine manufacturer's recommendations or at these intervals: Change the fluid more frequently if it becomes contaminated with foreign matter (dirt, water, grease, etc.) or if the fluid is subjected to temperature levels greater than the recommended maximum.

#### *Fluid and filter change interval*

| Reservoir type | Maximum change interval |
|----------------|-------------------------|
| Sealed         | 2000 hours              |
| Breather       | 500 hours               |

[Dispose of used hydraulic fluid properly. Never reuse hydraulic fluid.](#)

Change filters whenever the fluid is changed or when the filter indicator shows that it is necessary to change the filter. Replace all fluid lost during filter change.


**Pressure Measurements**

**Port Locations and Gauge Installation (130/145)**

The following table and drawing show the port locations and gauge sizes needed. When testing system pressures, calibrate pressure gauges frequently to ensure accuracy. Use snubbers to protect gauges.

| Port                 | Purpose              | Port size | Wrench size | Range of gauge |
|----------------------|----------------------|-----------|-------------|----------------|
| <b>L1, L2, L3</b>    | Case drain           | M26x1.5   | 12 mm       | 0-60 bar       |
| <b>M<sub>B</sub></b> | Outlet               | M12x1.5   | 6 mm        | 0-600 bar      |
| <b>M<sub>4</sub></b> | Servo piston chamber | M12x1.5   | 6 mm        | 0-600 bar      |

*130/145 Port locations, Control type: TPSN*




Pressure Measurements


Port Locations and Gauge Installation (193/260)

| Port           | Purpose              | Port size | Wrench size | Range of gauge |
|----------------|----------------------|-----------|-------------|----------------|
| L1, L2, L3     | Case drain           | M33x2     | 17 mm       | 0-60 bar       |
| M <sub>B</sub> | Outlet               | M12x1.5   | 6 mm        | 0-600 bar      |
| M <sub>4</sub> | Servo piston chamber | M12x1.5   | 6 mm        | 0-600 bar      |

193/260 Port location, Control type: TPE2



193/260 Port location, Control type: TPSN



P400092

## Initial Start-up Procedures

### General

Follow this procedure when starting-up a new D1 installation or when restarting an installation in which the pump has been removed.

Prior to installing the pump, inspect for damage incurred during shipping. Make certain all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with fluid.

### Start-up Procedure

1. Connect the pump to the prime mover.

Ensure that pump shaft is properly aligned with the shaft of the prime mover. Alignment should be within 0.25 mm and the angle must not exceed 0.2°.

 **Caution**

---

Incorrect shaft alignment may result in damage to drive shaft, bearings, or seal which can cause external oil leakage.

---

2. Fill the reservoir with recommended hydraulic fluid.  
Always filter fluid through a 10 micron filter pouring into the reservoir. Never reuse hydraulic fluid.
3. Fill the main pump housing with clean hydraulic fluid. Pour filtered oil directly into the upper most case drain port.
4. Fill the inlet line leading from the pump to the reservoir. Check the inlet line for properly tightened fittings and be certain it is free of restrictions and air leaks.
5. To ensure the pump stays filled with oil, install the case drain line in the upper most case drain port.
6. Install a gauge at port **MB** to monitor system pressure during start up.

---

[Follow recommendations in the vehicle / machine operator's manual for prime mover start up procedures.](#)

---

7. Switch system to free circulation or to lowest pressure, jog the prime mover or run at the lowest possible speed until pump and all pipes are filled and free from air bubbles. Raise pressure setting only when all air is removed.  
Let the pump work at reduced pressure for 5 - 10 min, check if all pipes and connections are leak free and tight.
8. Check the suction pressure at port **S** of the axial piston pump at nominal speed and maximum flow, make sure it is in allowable range.
9. Check the case drain pressure at the connected port **L1** or **L2** at maximum pressure, make sure it is in allowable range.
10. Shut down the prime mover and remove the pressure gauge. Replace plug at port **MB**.
11. Check the fluid level in the reservoir; add clean filtered fluid if necessary.

The pump is now ready for operation.

## Troubleshooting

### Excessive Noise and /or Vibration

| Item                                               | Description                                                                                                                                | Action                                                                                                                           |
|----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Check fluid level in reservoir.                    | Insufficient hydraulic fluid causes cavitation.                                                                                            | Fill the reservoir to proper level.                                                                                              |
| Check for air in system.                           | Air in system causes noisy, erratic control.                                                                                               | Purge air and tighten fittings. Check inlet for leaks.                                                                           |
| Check pump inlet pressure / vacuum.                | Improper inlet conditions cause erratic behavior and low output flow.                                                                      | Correct pump inlet pressure / vacuum conditions.                                                                                 |
| Inspect shaft couplings.                           | A loose or incorrect shaft coupling causes excessive noise and / or vibration.                                                             | Repair or replace coupling and ensure that correct coupling is used.                                                             |
| Check shaft alignment.                             | Misaligned shafts create excessive noise and / or vibration.                                                                               | Correct shaft misalignment.                                                                                                      |
| Hydraulic fluid viscosity above acceptable limits. | Hydraulic fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly. | Allow system to warm up before operating, or use fluid with the appropriate viscosity grade for expected operating temperatures. |

### Low Pump Output Flow

| Item                                                                                                          | Description                                                                                                                       | Action                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Check fluid level in reservoir.                                                                               | Insufficient hydraulic fluid will limit output flow and cause internal damage to pump.                                            | Fill the reservoir to proper level.                                                                                                               |
| Hydraulic fluid viscosity above acceptable limits.                                                            | Fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly.  | Allow system to warm up before operating, or use fluid with the appropriate viscosity grade for expected operating temperatures.                  |
| Check external system relief valve setting.                                                                   | External relief valve set below PC setting causes low output flow.                                                                | Adjust external relief valve following manufacturer's recommendation. External relief valve setting must be above PC setting to operate properly. |
| Check pressure compensate (PC), load sensing (LS) and power (T) control setting.                              | Low PC setting prevents the pump from achieving full stroke. Low LS setting limits output flow. Low T setting limits output flow. | Contact Danfoss Service.                                                                                                                          |
| Check LS control signal pressures.                                                                            | Incorrect LS signal will not allow pump to operate correctly.                                                                     | Inspect system to ensure that proper LS signal transmit to pump.                                                                                  |
| Check Pilot pressure for hydraulics displacement control and input current for electric displacement control. | Incorrect input signal causes low output flow.                                                                                    | Adjust input hydraulic or electric signal to right value.                                                                                         |
| Check pump inlet pressure / vacuum.                                                                           | High inlet vacuum causes low output flow.                                                                                         | Correct inlet pressure conditions.                                                                                                                |
| Check input speed.                                                                                            | Low input speeds decrease flow.                                                                                                   | Adjust input speed.                                                                                                                               |
| Check pump rotation.                                                                                          | Incorrect rotational configuration causes low flow.                                                                               | Use pump with appropriate rotational configuration.                                                                                               |

## Troubleshooting

### No or Low System Pressure

| Item                                                          | Description                                                   | Action                                                                                                                                            |
|---------------------------------------------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Check pressure compensate (PC) and power (T) control setting. | Low PC and T setting leads to low system pressure.            | Contact Danfoss Service.                                                                                                                          |
| Check external relief valve.                                  | External relief valve setting below PC setting.               | Adjust external relief valve according to manufacturer's recommendations. External relief valve must be set above PC setting to operate properly. |
| Check pilot pressure or control pressure.                     | Insufficient pilot pressure or control pressure.              | Increase them to appropriate value.                                                                                                               |
| Internal system leaks.                                        | Worn internal parts don't allow the pump to operate properly. | Refer to Authorized Service Center for required repair.                                                                                           |

### Actuator Response is Sluggish

| Item                                                                                                          | Description                                                                                                                                | Action                                                                                                                                               |
|---------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Check external system relief valve setting.                                                                   | Low external relief valve setting slows down system.                                                                                       | Adjust external relief valve setting following manufacturer's recommendations. External relief setting must be above PC setting to operate properly. |
| Check pressure compensate (PC), load sensing (LS) and power (T) control setting.                              | Low PC setting prevents the pump from achieving full stroke. Low LS setting limits output flow. Low T setting limits output Torque.        | Contact Danfoss Service.                                                                                                                             |
| Check LS control signal pressures.                                                                            | Incorrect LS signal will not allow pump to operate correctly.                                                                              | Inspect system to ensure that proper LS signal transmit to pump.                                                                                     |
| Check Pilot pressure for hydraulics displacement control and input current for electric displacement control. | Incorrect input signal causes low output flow.                                                                                             | Adjust input hydraulic or electric signal to right value.                                                                                            |
| Internal system leaks.                                                                                        | Worn internal parts don't allow the pump to operate properly.                                                                              | Refer to Authorized Service Center for required repair.                                                                                              |
| Hydraulic fluid viscosity above acceptable limits.                                                            | Hydraulic fluid viscosity above acceptable limits or low fluid temperature will not allow the pump to fill or control to operate properly. | Allow system to warm up before operation or use fluid with the appropriate viscosity grade for expected operating temperatures.                      |
| Check external system valving.                                                                                | Malfunctioning valving may not allow system to respond properly.                                                                           | Repair or replace system valving as required.                                                                                                        |
| Check pump case pressure.                                                                                     | High case pressure causes the system to be sluggish.                                                                                       | Correct case drain line restrictions.                                                                                                                |
| Check pump inlet pressure / vacuum.                                                                           | High inlet vacuum causes low output flow.                                                                                                  | Correct inlet pressure conditions.                                                                                                                   |

### Pressure or Flow Instability

| Item                     | Description                                                 | Action                                                                                                    |
|--------------------------|-------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| Check for air in system. | Air in system causes erratic operation.                     | Activate PC allowing system to bleed air. Check inlet line for leaks and eliminate source of air ingress. |
| Check LS setting.        | Low LS setting may cause instability.                       | Contact Danfoss Service.                                                                                  |
| Check LS signal line.    | Blocked LS signal line interferes with proper LS operation. | Remove blockage.                                                                                          |



### Troubleshooting

| Item                                        | Description                                                                      | Action                                                                                                                                       |
|---------------------------------------------|----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Check external relief valve and PC setting. | Insufficient pressure differential between PC setting and external relief valve. | Adjust external relief valve or PC control settings to appropriate level. Relief valve setting must be above PC setting to operate properly. |
| Check external relief valve.                | Chattering external relief valve may cause unstable feedback to pump control.    | Adjust or replace relief valve.                                                                                                              |

### System Operating Hot

| Item                                                                                     | Description                                                                                                                   | Action                                                                                                                                                             |
|------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Check fluid level in reservoir.                                                          | Insufficient volume of hydraulic fluid will not meet cooling demands of system.                                               | Fill reservoir to proper level. Verify proper size of reservoir.                                                                                                   |
| Inspect heat exchanger. Check air flow and input air temperature for the heat exchanger. | Insufficient air flow, high input air temperature, or undersized heat exchangers will not meet cooling demands of the system. | Clean, repair, or replace heat exchanger as required. Verify proper size of heat exchanger.                                                                        |
| Check external system relief valve setting.                                              | Fluid passing through relief valve adds heat to system.                                                                       | Adjust external system relief valve setting following manufacturer's recommendations. External relief valve setting must be above PC setting for proper operation. |
| Check pump inlet pressure / vacuum.                                                      | High inlet vacuum adds heat to system.                                                                                        | Correct inlet pressure / vacuum conditions.                                                                                                                        |

### High Inlet Vacuum

| Item                                               | Description                                                                         | Action                                                                      |
|----------------------------------------------------|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|
| Check fluid temperature.                           | Low temperature increases viscosity. High fluid viscosity causes high inlet vacuum. | Allow system to warm up before operating.                                   |
| Inspect inlet screen.                              | Blocked or restricted inlet screen causes high inlet vacuum.                        | Clean screen / remove blockage.                                             |
| Check inlet piping.                                | Too many fittings, bends, or long piping causes high inlet vacuum.                  | Eliminate fittings to make path more direct.                                |
| Hydraulic fluid viscosity above acceptable limits. | High fluid viscosity causes high inlet vacuum.                                      | Select fluid with appropriate viscosity for expected operating temperature. |

**! Caution**

High inlet vacuum causes cavitation which can damage internal pump components.

## Adjustments

### TPE2 Control (193/260)

TPE2+TPSN setting value is indicated in the pump model code, refer to *the D1 High Power Open Circuit Pump Technical Information Manual, L1426007* for more information.

Before performing adjustments, read [Pressure Measurements](#) on page 20.

#### Calculate Power Control Start Point Pressure and Corresponding Flow in Advance

1. Calculate the power control start point pressure according to the formula :  $\text{Power} = P \cdot n \cdot V_g \cdot 10^{-3} / (600 \cdot \eta)$ , (P: power control start point pressure, n : pump input speed,  $V_g$  : Pump theoretical displacement,  $\eta$  : total efficiency, set as 91.2%), the desired power setting is 90 kW, the pump input speed is 1500 rpm and the Pump theoretical displacement is 193 cc, then  $90 = P \cdot 1500 \cdot 193 \cdot 10^{-3} / (600 \cdot \eta)$ , so the power control start point pressure  $P = 170$  bar.
2. Choose the average pressure between power control start point pressure and Pressure compensated control setting, then calculate the corresponding flow. now the power control start point pressure is 170 bar, and Pressure compensated control setting is 320 bar, then the average pressure is  $(170 + 320) / 2 = 245$  bar, then calculate the flow according to the formula  $\text{Power} = P \cdot Q / (600 \cdot \eta)$ , for example :  $90 = 245 \cdot Q / (600 \cdot \eta)$ , the  $Q = 201$  l/min.

#### Electric Displacement Control Adjustment

3. Install a pressure gauge in port **MB** to measure outlet pressure, Install a flow meter in outlet line to measure pump flow.

#### **Warning**

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. Relieve pressure in the system before removing hoses, fittings, gauges, or components.

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable / disconnect the mechanism while servicing.

#### **Caution**

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.

4. Start the prime mover and input 700 mA to electric displacement control solenoid valve, then allow fluid to reach normal operating temperature.
5. Totally lock the power control which means firstly loosen the power control lock nut and turn the power control adjusting screw clockwise to the end, while holding the power control adjusting screw, torque the the power control lock nut to 21.6~24.6 N·m.
6. Totally lock the pressure compensated control which means firstly loosen the power control lock nut and turn the pressure compensated control adjusting screw clockwise to the end, while holding the pressure compensated control adjusting screw, torque the the power control lock nut to 21.6~24.6N.m.
7. Input 400mA to electric displacement control and load the pump outlet pressure to 50 bar, then loosen the electric displacement control lock nut and turn its adjusting screw until the pump displacement achive (see Table 1) which can calculated by monitoring pump outlet flow and pump speed. Clockwise turning adjusting screw decrease pump displacement, counterclockwise truning increase pump displacement, the displacement - current curve will offset (see Table 2) per turn.
8. While holding the position of the electric displacement control adjusting screw, torque the lock nut to 9.5 N·m.

## Adjustments

9. Input 500 mA to electric displacement control, check if the displacement is around (see Table 1) at this moment, if it is, the electric displacement control adjustment complete, if it is not, please re-adjust.

Table 1

| Input Current | Size 193 | Size 260 |
|---------------|----------|----------|
| 400 mA        | 92.5 cc  | 140.5 cc |
| 500 mA        | 115.5 cc | 172.5 cc |

Table 2

| Per Turn | Size 193 | Size 260 |
|----------|----------|----------|
| Offset   | 263 mA   | 263 mA   |

### Pressure Compensated Control Adjustment

10. Input 700 mA to electric displacement control to make sure the pump is at maximum displacement.
11. Load the pump outlet pressure to at least 30 bar higher than expected pressure compensated control setting.
12. Loosen the Pressure compensated control lock nut and turn the Pressure compensated control adjusting screw until the desired setting is indicated on the pressure gauge at port **MB**. Clockwise rotation increases pressure, counterclockwise rotation decreases; approximate gain (see Table 3) per turn, while holding the Pressure compensated control adjusting screw, torque the the Pressure compensated control lock nut to 21.6~24.6 N·m.

Table 3

|                 | Size 193  | Size 260  |
|-----------------|-----------|-----------|
| Change per turn | 163.2 bar | 163.2 bar |

[If the pressure does not increase, an external system relief valve may require adjustment. External system relief valve must be set above the Pressure compensated control setting for proper operation.](#)

### Power Control Adjustment


13. Load the pump outlet pressure to 253 bar, loosen the power control lock nut and turn power control adjusting screw and monitor the flow meter, when the flow meter shows the flow is 201 l/min, stop turning, while holding the position of power control adjusting screw, torque the power control lock nut to 21.6~24.6 N·m. Clockwise rotation increases power, counterclockwise rotation decreases approximate gain per turn (See Table 4).

Table 4

|                 | Size 193 | Size 260 |
|-----------------|----------|----------|
| Change per turn | 73.5 kW  | 99 kW    |

**Adjustments**

**14.** Stop the prime mover, remove the pressure gauge and flow meter, and return the system to its normal operating configuration.



## Adjustments

### TPSN Control (193/260)

#### Power Control and Pressure Compensated Control Adjustments

1. Calculate power control start point pressure and corresponding flow in advance, see step 1, 2 in [Calculate Power Control Start Point Pressure and Corresponding Flow in Advance](#) of TPE2 control adjustments.
2. Install a pressure gauge in port **MB** to measure outlet pressure, Tee-in a pressure gauge to the LS signal line (port **X**) to measure LS signal pressure, Install a flow meter in outlet line to measure pump flow.
3. Start the prime mover and allow fluid to reach normal operating temperature.
4. Totally lock the LS control which means firstly loosen the LS control lock nut and turn the LS control adjusting screw clockwise to the end, while holding the LS control adjusting screw, torque the LS control lock nut to 21.6~24.6 N·m.
5. Then adjust power control and pressure compensated control according to the steps 5, 6, 11, 12, 13 of TPE2 control.

#### Load Sensing Control Adjustment

6. After step 5, Slowly operate a hydraulic function that will demand approximately half flow from the pump, but keep outlet pressure below the power control pressure turning point.

#### **Warning**

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. Relieve pressure in the system before removing hoses, fittings, gauges, or components.

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable / disconnect the mechanism while servicing.

#### **Caution**

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.


7. Loosen the LS control lock nut. While watching the pressure gauges, turn the LS control adjusting screw counterclockwise until the desired pressure differential between port **MB** and port **X** is achieved. Clockwise rotation increases the setting, counterclockwise rotation will decrease it; approximate gain (see Table 5) per turn. While holding the position of the LS adjusting screw, torque the LS lock nut to 21.6~24.6 N·m.

Table 5

|                 | Size 193 | Size 260 |
|-----------------|----------|----------|
| Change per turn | 26.4 bar | 26.4 bar |

**Adjustments**

**8.** Stop the prime mover, remove the pressure gauge and flow meter, and return the system to its normal operating configuration.



## Adjustments

### TPSN Control (130/145)

The specific adjustment steps please refer to [193 TPSN](#) adjustment steps.

#### **Warning**


Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. Relieve pressure in the system before removing hoses, fittings, gauges, or components.

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable / disconnect the mechanism while servicing.

#### **Caution**

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.

The wrench sizes and torques please check below drawing



P400255

Change per turn of each adjustment bolt

| Control Type | Change per Turn                         |
|--------------|-----------------------------------------|
| T            | 39KW@1500rpm, (50.8kw@1500rpm for TPE5) |
| P            | 271bar, (163.2bar for TPE5)             |
| S            | 50 bar                                  |
| N            | -                                       |

## Adjustments

### Displacement Limiters Adjustment

#### Adjust Displacement Limiters

**⚠ Warning**

Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury and/or infection. Relieve pressure in the system before removing hoses, fittings, gauges, or components.

Unintended movement of the machine or mechanism may cause injury to the technician or bystanders. To protect against unintended movement, secure the machine or disable / disconnect the mechanism while servicing.

**⚠ Caution**

Contamination can damage internal components and void the manufacturer's warranty. Take precautions to ensure system cleanliness when removing and reinstalling system lines.

1. Install a flow meter in outlet line to measure pump flow.
2. Start the prime mover and allow fluid to reach normal operating temperature.
3. Adjust the control properly to make sure the pump at maximum displacement.
4. Loosen the maximum or minimum displacement limiter lock nut with an external hex wrench and turn the adjusting screw with an internal hex wrench until the desired flow is achieved.

| Option               | Description                                                                                                                                        |
|----------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Maximum displacement | <ul style="list-style-type: none"> <li>• Clockwise turn decreases displacement</li> <li>• Counter-clockwise turn increases displacement</li> </ul> |
| Minimum displacement | <ul style="list-style-type: none"> <li>• Clockwise turn increases displacement</li> <li>• Counter-clockwise turn decreases displacement</li> </ul> |

*Displacement change per turn*

|                                   | 130/145                 | 193                     | 260                     |
|-----------------------------------|-------------------------|-------------------------|-------------------------|
| Max. displacement change per turn | 11 cm <sup>3</sup> /rev | 15 cm <sup>3</sup> /rev | 19 cm <sup>3</sup> /rev |
| Min. displacement change per turn | 9 cm <sup>3</sup> /rev  | 14 cm <sup>3</sup> /rev | 18 cm <sup>3</sup> /rev |

5. While holding the position of the adjusting screw, torque the lock nut to required torque.

*Wrench sizes and Torque*

|        | 130/145   | 193         | 260         |
|--------|-----------|-------------|-------------|
| Screws | 5 mm      | 8 mm        | 8 mm        |
| Nuts   | 17 mm     | 24 mm       | 24 mm       |
|        | 43~48 N·m | 180~206 N·m | 180~206 N·m |



## Minor Repair

### Shaft Seal Replacement


D1 pump uses a lip-type shaft seal. You can replace this seal without major disassembly of the unit. Replacing the shaft seal requires removing the pump from the machine.

#### Removal

1. Using the appropriate snap-ring pliers, remove the retaining ring (F210) from the housing.
2. Remove the shaft seal and its carrier (F220) with appropriate tool (like 2 straight screwdriver) from the bore in the pump housing and discard.
3. Remove the O-ring (F230) and discard.

#### Installation

1. Inspect the pump housing and new seals for damage. Inspect the sealing area on the shaft for rust, wear, or contamination. Polish the sealing area on the shaft if necessary.
2. Lubricate new O-ring (F230) with petroleum jelly and fit in the housing groove.
3. Lubricate the lip of the new shaft seal with clean hydraulic fluid. Place a protective sleeve over the shaft end to prevent damage to the seal during installation.
4. Keeping the new seal and its carrier perpendicular to the shaft, press them into the housing just far enough to clear the retaining ring groove. Install seal with the cupped side toward the shaft bearing. Do not damage the seal during installation.
5. Using the appropriate snap ring pliers, install the seal retaining ring.
6. Remove the installation sleeve.



P400096

**Minor Repair**

**Auxiliary Flange and Charge Pump Replacement**

Follow these steps to either remove, replace, or exchange auxiliary mounting pads and charge pump.

**Removal**


1. Remove the screws (H140), retaining the cover plate (H150). Remove the seal (H130).
2. Remove the drive coupling (H200) if present.
3. Remove the 4 screws (H120), retaining the pad adapter (H100) to the endcap. Discard the pad adapter O-ring (H110).
4. Use the appropriate snap-ring pliers, remove the retaining ring (G610) from the shaft.
5. Pull out the charge pump, if it is damaged, discard it.

**Installation**

1. Push in the new charge pump far enough to clear the retaining ring groove.
2. Use the appropriate snap-ring pliers to install retaining ring (G610) onto the shaft.
3. Lubricate new O-ring (H110) with petroleum jelly. Install the pad adapter to the endcap.
4. Install the 4 screws (H120) and torque to required torques.
5. Install the drive coupling (H200) if present.
6. Install the cover (H150) with seal (H130), lubricate the seal with petroleum jelly.
7. Install the screws (H140) and torque to required torques.

**130/145**


All torques tolerance  $\pm 10\%$



**Minor Repair**

**193/260**

All torques tolerance  $\pm 10\%$



\* E3 option is only for 260.

**Minor Repair**

**Control (193/260)**

**Removal**

1. Remove the TPE2 control from the endcap by removing the 3 long control bolts (D170) and 2 short bolts (D180), TPSN control are 5 short bolts (D175).


The sleeve-TC Jack (D640) might stay on the hole of bias piston in endcap, remove and place it with control.

2. Remove and discard the Seals, 193: O-ring (D140) and 3 other O-ring (D150), 260: gasket (D145).

**Installation**


1. Lubricate new Seals, 193: O-ring (D140) and 3 small O-ring (D130), 260: gasket (D145) with petroleum jelly and fit in the control housing grooves.
2. Make sure TC jack sleeve (D640) is set in bias piston hole, then install the control housing assembly onto the endcap using the 3 long screws (D170) and 2 short screws (D180). TPSN control use 5 short screws (D175).

*193/260 TPE Control*



P400293

*193/260 TPSN Control*




P400294

**Minor Repair**

**Control (130/145)**

*TPSN Control*



**Minor Repair**

**Shuttle Valve or Plug**

**Removal**

1. For TPE2 control, first remove the plug assy-HEX(D900).
2. Then pull out shuttle vale seat(D920) with a M6 screw.
3. At last remove the spool(D910) with an appropriate tool.
4. For TPSN control, here is only a plug, normally no need to remove.

**Installation**

1. For TPE2 control, coat the shuttle valve spool (D910) with cleaning hydraulic oil and install to E port in the endcap.
2. Install shuttle valve seat(D920) according to the direction showing in the picture.
3. Install E port plug assembly(D900).
4. If the shuttle valve is not used, replace it with the plug (D900).


**Edge Filter (260)**

**Removal**

1. Remove the plug G255.
2. Then, remove the filter G254.

**Installation**

1. First, install the filter G254, torque to required torque.
2. Then, install the plug G255, torque to required torque.



## Minor Repair

### Displacement Limiters

#### Removal

The removal steps of the maximum (bottom of the pump) and minimum (top of the pump) are the same.

1. Loosen the lock nut (F120) with an external hex wrench.
2. Counter clockwise turn the adjusting screw (F110) with 8mm internal hex wrench until it totally out.
3. Inspect the lock nut seal and adjusting screw, if they are damaged , discard them.


#### Installation

The installation steps of the maximum (bottom of the pump) and minimum (top of the pump) are the same.

1. Clockwise turn the adjusting screw (F110) with 8mm internal hex wrench until you feel it start against the swashplate.
2. Install the lock nut (F120), while holding the adjusting screw position, torque the lock nut to required torque.

Table 1 : Wrench sizes and Torque

|        | 130/145   | 193         | 260         |
|--------|-----------|-------------|-------------|
| Screws | 5 mm      | 8 mm        | 8 mm        |
| Nuts   | 17 mm     | 24 mm       | 24 mm       |
|        | 43~48 N·m | 180~206 N·m | 180~206 N·m |




P400265

**Minor Repair**

**Plug and Fitting Sizes and Torques**

If any plugs or fittings are removed from the unit during service, install and torque as indicated here. This drawing is a composite. Your configuration may differ but here is the appropriate wrench size and torque:

**193 TPE2 Control**




P400266




Minor Repair

260 TPE2 Control




130/145 TPSN Control




**Minor Repair**

**Torque Chart**

**Size 193/260**



**Size 130/145**



**Fastener Size and Torque Chart**

All torques tolerance (except already given range) :  $\pm 10\%$

| Item         | Fastner                        | 130/145            |             | 193                |               | 260                |               |
|--------------|--------------------------------|--------------------|-------------|--------------------|---------------|--------------------|---------------|
|              |                                | Wrench size        | Torque      | Wrench size        | Torque        | Wrench size        | Torque        |
| D170<br>D180 | Control assembly screws        | N/A                | N/A         | 6 mm internal hex  | 25 N·m        | 6 mm internal hex  | 25 N·m        |
| D175         | Control assembly screws        | 6 mm internal hex  | 25 N·m      | 6 mm internal hex  | 25 N·m        | 6 mm internal hex  | 25 N·m        |
| H120         | Adapter screws                 | 10 mm internal hex | 130 N·m     | 14 mm internal hex | 215 N·m       | 14 mm internal hex | 215 N·m       |
| F110         | Displacement limiter screws    | 5 mm internal hex  | N/A         | 8 mm internal hex  | N/A           | 8 mm internal hex  | N/A           |
| D370         | P adjusting screw              | 4 mm internal hex  | N/A         | 4 mm internal hex  | N/A           | 4 mm internal hex  | N/A           |
| D470         | T adjusting screw              | 4 mm internal hex  | N/A         | 4 mm internal hex  | N/A           | 4 mm internal hex  | N/A           |
| D870         | S adjusting screw              | 4 mm internal hex  | N/A         | 4 mm internal hex  | N/A           | 4 mm internal hex  | N/A           |
| D110         | E2 adjusting screw             | N/A                | N/A         | 3 mm internal hex  | N/A           | 3 mm internal hex  | N/A           |
| F120         | Displacement limiter lock nuts | 17 mm external hex | 43 - 48 N·m | 24 mm external hex | 180 - 206 N·m | 24 mm external hex | 180 - 206 N·m |

**Minor Repair**

All torques tolerance (except already given range) :  $\pm 10\%$  (continued)

| Item | Fastner    | 130/145            |               | 193                |               | 260                |               |
|------|------------|--------------------|---------------|--------------------|---------------|--------------------|---------------|
|      |            | Wrench size        | Torque        | Wrench size        | Torque        | Wrench size        | Torque        |
| D380 | P locknut  | 13 mm external hex | 21.6-24.6 N·m | 13 mm external hex | 21.6-24.6 N·m | 13 mm external hex | 21.6-24.6 N·m |
| D480 | T locknut  | 13 mm external hex | 21.6-24.6 N·m | 13 mm external hex | 21.6-24.6 N·m | 13 mm external hex | 21.6-24.6 N·m |
| D880 | S locknut  | 13 mm external hex | 21.6-24.6 N·m | 13mm external hex  | 21.6-24.6 N·m | 13mm external hex  | 21.6-24.6 N·m |
| D120 | E2 locknut | N/A                | N/A           | 10 mm external hex | 9.5 N·m       | 10 mm external hex | 9.5 N·m       |

**Plug Size and Torque Chart**

All torques tolerance (except already given range) :  $\pm 10\%$

| Item         | 130/145      |                    |        | 193          |                    |         | 260          |                    |         |
|--------------|--------------|--------------------|--------|--------------|--------------------|---------|--------------|--------------------|---------|
|              | ED-ring plug | Wrench size        | Torque | ED-ring plug | Wrench size        | Torque  | ED-ring plug | Wrench size        | Torque  |
| F140<br>F150 | M26X1.5      | 12 mm internal hex | 76 N·m | M33X2        | 17 mm internal hex | 225 N·m | M33X2        | 17 mm internal hex | 225 N·m |
| G225<br>G235 | M12X1.5      | 6 mm internal hex  | 25 N·m | M12X1.5      | 6 mm internal hex  | 25 N·m  | M12X1.5      | 6 mm internal hex  | 25 N·m  |

**Products we offer:**

- Bent Axis Motors
- Closed Circuit Axial Piston Pumps and Motors
- Displays
- Electrohydraulic Power Steering
- Electrohydraulics
- Hydraulic Power Steering
- Integrated Systems
- Joysticks and Control Handles
- Microcontrollers and Software
- Open Circuit Axial Piston Pumps
- Orbital Motors
- PLUS+1® GUIDE
- Proportional Valves
- Sensors
- Steering
- Transit Mixer Drives

**Danfoss Power Solutions** is a global manufacturer and supplier of high-quality hydraulic and electronic components. We specialize in providing state-of-the-art technology and solutions that excel in the harsh operating conditions of the mobile off-highway market. Building on our extensive applications expertise, we work closely with our customers to ensure exceptional performance for a broad range of off-highway vehicles.

We help OEMs around the world speed up system development, reduce costs and bring vehicles to market faster.

Danfoss – Your Strongest Partner in Mobile Hydraulics.

**Go to [www.powersolutions.danfoss.com](http://www.powersolutions.danfoss.com) for further product information.**

Wherever off-highway vehicles are at work, so is Danfoss. We offer expert worldwide support for our customers, ensuring the best possible solutions for outstanding performance. And with an extensive network of Global Service Partners, we also provide comprehensive global service for all of our components.

Please contact the Danfoss Power Solution representative nearest you.

**Comatrol**

[www.comatrol.com](http://www.comatrol.com)

**Turolla**

[www.turollaocg.com](http://www.turollaocg.com)

**Hydro-Gear**

[www.hydro-gear.com](http://www.hydro-gear.com)

**Daikin-Sauer-Danfoss**

[www.daikin-sauer-danfoss.com](http://www.daikin-sauer-danfoss.com)

Local address:

**Danfoss Power Solutions (US) Company**  
2800 East 13th Street  
Ames, IA 50010, USA  
Phone: +1 515 239 6000

**Danfoss Power Solutions GmbH & Co. OHG**  
Krokamp 35  
D-24539 Neumünster, Germany  
Phone: +49 4321 871 0

**Danfoss Power Solutions ApS**  
Nordborgvej 81  
DK-6430 Nordborg, Denmark  
Phone: +45 7488 2222

**Danfoss Power Solutions Trading (Shanghai) Co., Ltd.**  
Building #22, No. 1000 Jin Hai Rd  
Jin Qiao, Pudong New District  
Shanghai, China 201206  
Phone: +86 21 3418 5200

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.